

说明书成品尺寸：74.4*145.4mm




Table of Contents	
Safety Information	01
Introduction	02
Call Functions	03
Contacts	05
Message	07
Internet Browser	09
Bluetooth & Wi-Fi	10
Camera	12
Gallery	13
Music	15
Sound Recorder	15
Alarm Clock	16
Google Play	17
Settings	18
Storage	21
FCC Rules Compliance	22
IC Notice	24

Safety Information

Please carefully read the terms below:

Use Safety
Do not use the phone in situations where it might cause danger. Please drive with caution on the road.

Transportation Safety
Please observe all transportation laws and regulations. Please drive with caution on the road.

DO NOT TEXT AND DRIVE

Hospitals
Please follow instructions. Please turn off your mobile phone when near medical equipment.

Aerosols
Remember to follow all airport and flight safety regulations. Please do not use your phone during flight.

Toxic Chemicals
Do not use your mobile phone around fuels or chemicals.

Hazard
Do not use in hazardous areas where explosions may occur.

Accessories and Batteries
Use only FCC authorized batteries and accessories.

Backup
Remember to keep a written record of all important information.

Water
Your phone is not waterproof. Keep it away from water and liquids.

SOS Emergency Calls
Make sure your mobile phone is switched on and in a service area. In home screen, tap the phone key and dial 911 and send.

Introduction

Power On and Off
On - Please ensure the SIM card has been properly inserted into the phone. Long press the Power key to switch on the phone.
Off - In standby mode, long press on Power key until an options menu appears. Select Power Off in the menu and confirm.

Security
You may set a security lock feature as a security measure for the phone. For further information regarding password locks, password rotation and other functions please enter into the security option in system settings.

Call Functions

At the dial pad, enter the phone number and then click the dial key. If dialing an extension, you may click the dial pad on the bottom of the screen to open the dial pad and enter the number of the extension. You may also press and hold the dial key to add a (*) sign when dialing an international dialing prefix.

Call Options
There are different colors that can be used in the history and dialing interface. You may press the MISC. icon in the dial interface and adjust speed dial and call settings. In the dialing interface, you may press the search button to browse through contacts list or set default contact resource.

Call History
You may set a security lock feature as a security measure for the phone. For further information regarding password locks, password rotation and other functions please enter into the security option in system settings.

Messages

Every telephone number called and received will be saved in the history. All numbers in the history can be dialed directly by clicking the CALL BACK on the screen. When the number returns to the list, click to view details.

Call Options
There are different colors that can be used in the history and dialing interface. You may press the MISC. icon in the dial interface and adjust speed dial and call settings. In the dialing interface, you may press the search button to browse through contacts list or set default contact resource.

Send an SMS
When composing messages, the default message title is SMS. The message will automatically convert to MMS when adding an attachment.

Send an MMS
When composing messages, the default message title is MMS. The message will automatically convert to MMS when adding an attachment.

Internet Browser

Recent Functions
After browsing through multiple pages, this option will return the user to the previous page.

Bookmarks
You may view all websites open by clicking the bookmark icon in the upper right part of the browser. Bookmarks will be saved in the browser.

Power on Bluetooth
Bluetooth is a short-range wireless communications technology that can be used to exchange information and connect to other types of devices which include mobile devices.

Camera

Power on Wi-Fi
1) Settings >> Wi-Fi and select ON to power on Wi-Fi.
2) Click on the desired Wi-Fi network to be connected. A network name can be connected to identify. A password network requires a password or credentials prior to connection.

Camera
Press to take photos or videos before using the camera or video camera. All photos or videos taken for the camera are typically stored in the memory card for large storage capacity of images.

Open Camera
1. Aim the object that the picture will be taken.
2. Press the "Shutter" button on the screen.
3. After taking the picture, the file will be saved in the camera's gallery folder.
4. You may view the photos by clicking the preview box button. You may adjust various settings for the camera by pressing Menu while in the camera interface. When in the camera's gallery folder, you can switch to video or photo gallery.

Gallery

Open Images
Applications Menu >> Gallery

Share Pictures
You may share photos by sending them through different types of installed applications. You may also send pictures through the SMS message function by composing a message or attaching the picture. Any image can also be sent via the Bluetooth function by selecting a Bluetooth recipient that has been paired.

Adjust Image
Press Menu and Edit to adjust images. You may select from different filters that may include: Vintage, Black and White, Instant, Luma, Luma, X-Process, Crop, Rotate, Mirror, Straighten, Vibrance, Contrast, Exposure, Auto color, Shadow, Vibrance, among other settings that can be used to adjust picture images.

View Images
In the picture interface, click on an album to view images in the photo album, scroll the picture boards left to view the next album or boards right to view the previous one.

Crop Pictures
If you want to adjust the size of the picture, use the crop tools. Once the area appears, pinch your finger in out to adjust the image. If you want to adjust the image and keep the proportion, please hold down any of the four corners of the image and adjust accordingly.

Music

Open Music
Click on the Clock icon in the application menu. Applications Menu >> Music

Search Music
You may choose to search for music from media folder through either name, song name, album name. The following formats are available: AMR, M4R, MP3, WAV, and OGG. You may also search for music from the internet.

Adjust Image
Press Menu and Edit to adjust images. You may select from different filters that may include: Vintage, Black and White, Instant, Luma, Luma, X-Process, Crop, Rotate, Mirror, Straighten, Vibrance, Contrast, Exposure, Auto color, Shadow, Vibrance, among other settings that can be used to adjust picture images.

View Images
In the picture interface, click on an album to view images in the photo album, scroll the picture boards left to view the next album or boards right to view the previous one.

Crop Pictures
If you want to adjust the size of the picture, use the crop tools. Once the area appears, pinch your finger in out to adjust the image. If you want to adjust the image and keep the proportion, please hold down any of the four corners of the image and adjust accordingly.

Alarm Clock

1. Click on the Clock icon in the application menu. Applications Menu >> Music

Sound Recorder
The Sound Recorder can record voice or any audio. You may select from different filters that may include: Vintage, Black and White, Instant, Luma, Luma, X-Process, Crop, Rotate, Mirror, Straighten, Vibrance, Contrast, Exposure, Auto color, Shadow, Vibrance, among other settings that can be used to adjust picture images.

View Images
In the picture interface, click on an album to view images in the photo album, scroll the picture boards left to view the next album or boards right to view the previous one.

Crop Pictures
If you want to adjust the size of the picture, use the crop tools. Once the area appears, pinch your finger in out to adjust the image. If you want to adjust the image and keep the proportion, please hold down any of the four corners of the image and adjust accordingly.

Google Play

Google Play allows you to download music, movies, and even games. Click the Play icon to sign with your Google account.

Set up SIM card PIN lock
SIM card PIN (Personal Identification Number) is used to prevent unauthorized use of SIM card.

Date & Time
Date and Time adjustment: Time Zone - Select Time Zone according to where your location is.

Backup
Backup - Back up all application data, WLAN preferences, and other settings to Google's servers.

Repeat options
Repeat options - When using the GPS, power on set satellite positioning for accurate.

About phone
Phone information status and build number.

Storage

Connect the phone with the USB cable provided. Once connected, a connection window will appear in the connection mode interface, select MTP and turn on from the connection mode. The USB icon will appear on the phone screen and also available.

Regulatory Information
FCC Rules Compliance
This mobile phone complies with part 15 of the FCC rules, and other settings to Google's servers.

RF Exposure Information (SAR)

The information provided in this user manual is subject to change without notice and FCC regulations reserve the right to change without notice and FCC regulations reserve the right to change without notice and FCC regulations reserve the right to change without notice.

Additional Information
The information provided in this user manual is subject to change without notice and FCC regulations reserve the right to change without notice and FCC regulations reserve the right to change without notice.

IC Notice

This device complies with Industry Canada license-exempt RSS (standards). Operation is subject to the following two conditions: (1) This device must not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

IC Radiation Exposure Statement
This EUT is in compliance with SAR for general population/uncontrolled exposure. The SAR value for this device is 1.61 W/kg (head) and 0.45 W/kg (body) and has been tested to be in compliance with the maximum SAR value of 2.0 W/kg (head) and 1.0 W/kg (body) for general population/uncontrolled exposure.